Feature operation

reature operation			
AutoDial			
Store	AutoDial		AutoDial
Use		AutoDial	
Display	Display	AutoDial	
Call Forward			
Activate	Fwd		► Fwd
Deactivate	▶ Fwd		
Reinstate	Fwd	▶ Fwd	
View number	Display	▶ Fwd	
Call Pickup		Pickup	
Call Waiting			
Answer	(Hold)	Call Waiting	
Return to first call	(Goodbye)		
Conference	Conf		▶ Conf
Handsfree			
Activate	(Handsfree)	(Goodbye) (t	o end the call)
Switch to handset			
Handset to handsfree	(Handsfree)		
Activate Headset	(Headset)	(Goodbye) (t	o end the call)
Hold			
Place a call on hold	(Hold)		
Return to a held call			
Last Number Redial			
Message		(Msg/Inbox)	
Ring Again			
Activate	RngAgn		
When notified		RngAgn	
Deactivate	RngAgn		
Transfer	Trans		▶ Trans
Adjust volume	(Volume +)	or (Volume -)	

Legend

U	
Icon	Action
()	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the line (DN) key or the Handset key.
	Replace the handset, or press (Goodbye) to end the call.

Legend (continued)

₽


	Λ - Δ'			
Icon	Action			
	Press a line/feature key.			
	Dial a number.			
AutoDial	An icon flashes when a feature is being programmed. An icon lights steadily when a feature is active.			
A	Press the Services key once for Call Platform features, or press the Services key twice for local phone features.			
四	Press the Message/Inbox key.			
\bigcirc	Press the Up/Down Navigation keys			
4	Press the Enter key			
91	Press the Headset key.			
	Press the Handsfree key.			
1 4	Press the Mute (on/off) key.			
(A)	Press the Directory key.			
0	Press the Quit/Stop key.			

Services and Telephone Options menus Services menu

(Services)
Note: The Services menu contains the Telephone Options, Password
Admin, Virtual Office, and MG 1000B menus. These options are not available
on all Nortel IP Phone 1120E phones. Consult your system administrator.
he following are the most commonly used options:
elephone Options menu

Volume adjustmen	t					
Pick one of: Ringer Handset Listen Handsfree Listen Headset Listen Buzzer	Ţ	٥	ų.	(Quit)		
Contrast adjustment						
	4	(Qu	uit)			
Language						
	4	(Qu	uit)			
Note: This language setting controls the language used by features on						

Note: This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.



Note: The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 1120E, consult the *Nortel IP Phone 1120E User Guide* (NN43112-103).

Nortel IP Phone 1120E



*Note: If supported by your server, the data message waiting indicator provides a data alert. Contact your system administrator to find out if this feature is available for you.



www.nortel.com

IP Phone 1120E

For Nortel Communication Server 1000

Quick Reference Card



Date: May 2007

Document Release: Standard 01.01 Document Number: NN43112-106 Copyright © 2006–2007 Nortel Networks. All Rights Reserved.

* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.